

Ford Focus 1.8 Tddi 1998-2005

1. Open the connection plug from the VP-Pump and connect the box adapter between. The box type is VT101101.

