

Chrysler Grand Voyager 2.8 CDRi 2007

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

