


VW Golf 2.0TDI 140HP

1. Box type: VT101302.

2. Find plug for injector harness. Disconnect it and connect box adapter between.



3. Connect black (-) and red (+) wires to battery.