

BMW 320td 150HP 2004

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

