

Jaguar X-type 2.0 D 2005

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

