

## Honda CR-V 2.2i-CDTi 140HP 2004

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

