

Mazda 626 2.0CD 143HP 2007

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

